

## CIB-INPUT/MULTI-LIST

2006/5/27

CH	INPUT	MIC	STAND	INSERT-I/O	下手MULTI	上手MULTI
1	MC-1	565-SD			1	-
2	MC-2	565-SD			2	-
3	F.T-LOW	AUDIX D-2			-	1
4	F.T-HI	AUDIX D-2			-	2
5	T.T-LOW	AUDIX D-2			-	3
6	T.T-HI	AUDIX D-2			-	4
7	SN	AUDIX D-1			-	5
8	KICK	AUDIX D-6			-	6
9	GK-LINE				7	-
10	GK-MIC	AUDIX D-6			8	-
11	KEY-L	ULTRA-DI			5	-
12	KEY-R	ULTRA-DI			6	-
13,14	SUB-MIX	CD/MD/DVD			-	-
15,16	REV				-	-
17	下手コンデンサー	RODE NT1-A			9	-
18	上手コンデンサー	RODE NT1-A			-	10
19	PF-LOW	RODE NT5			3	-
20	PF-HI	RODE NT5			4	-
21	JC-120	SM57			-	7
22	FENDER	SM57			-	8
23	PF-VO	SM58			10	-
24	DRUM-VO	SM58			-	9
25	VOX-1	SM58			11	-
26	VOX-2	SM58			12	-
27	EXT-1				-	13
28	EXT-2				-	14
29	EXT-3				-	15
30	EXT-4				-	16
31	天井-L	RODE NT5			-	-
32	天井-R	RODE NT5			-	-

	OUT-PUT	EQ	AMP	SPEAKER	下手MULTI	上手MULTI
MAIN-L	HOUSE-L	BEHRINGER	EV-CP2200	EV/T-252+	A	-
MAIN-R	HOUSE-R	BEHRINGER	EV-CP2200	EV/T-252+	B	-
M5	DRUM		CP-CP1000	CP12M	C	-
M6	KEY		CP-CP1000	CP12M	D	-
M7	FOOT	DBX	EV-CP2200	CP12M x 2	-	C
M8	SIDE	DBX	EV-CP2200	EV/T-251+ x2	-	D
M9						
M10	REV		BEHRINGER	TO-ch15,16		